




Le Mans

1000

WORKSHOP MANUAL



COD. 28920161


Additions to the Workshop manual for the models V1000 G5 e 1000 SP - Cod. 17 92 01 61

The illustrations and descriptions in this booklet are indicative only and the manufacturer reserves itself the right to introduce any modification it may deem necessary for better performance or for constructive or commercial reasons at any time and without prior notice.

SEIMM MOTO GUZZI - TECHNICAL PUBLICATIONS

COD. 28920161

200 - 4/87 - Printed in Italy - D.E.Ca - Ravenna



305

DIRECTION FOR A CORRECT USE OF THE VEHICLE

We remind that this model, due to its exceptional peculiarities, is almost a racing bike requiring a sport riding.

For this reason it meets so much fans' favour but, as for racing bikes, the technique of its use must be adequate.

First of all we have to evaluate that it fits carburettors with fuel feed pumps and when throttle control is not correctly operated in connection with engine revolutions per minute, a petrol overflow can be determined, causing coming out by the same carbs. and finishing inside the air cleaner.

When riding at idle speed or better, at a low r.p.m. range, it is necessary that throttle valve opening is graduated since a larger quantity of fuel could be not absorbable by the engine; at a very high r.p.m. range, also with strong accelerating action, fuel is totally absorbed and used, giving the bike that smart acceleration it is famous for.

243

INDEX

2 **MAIN SPECIFICATIONS** page 246

5 **CHECKING DEVICES AND CONTROLS** page 248

- 1 Dashboard
- 4 Light switch - horn push-button and direction indicators
- 6 Start push-button - engine stop and light control switches
- 18 Fuse holding box
- 23 Saddle locking device

6 **MAINTENANCE AND ADJUSTMENTS** page 250

- 1 Clutch lever adjustment
- 2 R.H. front brake lever adjustment
- 4 Rear suspensions adjustment
- 8 Headlight beam adjustment

7 **MAINTENANCE AND LUBRICATION OPERATIONS** page 252

12 **ENGINE OVERHAULING AND CHECKING** page 253

- 6 Valves and valve-guides
- 8 Valve springs
- 12 Cylinders
- 13 Pistons

13 **TIMING** page 256

- 1 Timing data
- 7 Tappet clearance

15 **FUEL FEEDING** page 257

- 1 Carburetors
- 6 Air cleaner replacement

20 **21** **SUSPENSIONS** page 259

22 **SWINGING FORK** page 262

23	WHEELS	page 263
-----------	---------------	-----------------

- 20 Front wheel
- 21 Rear wheel
- 22 Tyres
- 23 Hydraulic brake systems

24	ELECTRIC SYSTEM	page 267
-----------	------------------------	-----------------

25	ELECTRIC SYSTEM SCHEME	page 268
-----------	-------------------------------	-----------------

ENGINE	4-stroke, twin cylinders
— cylinder configuration	90° «V» twin
— bore	88 mm
— stroke	78 mm
— total capacity	948.8 cc
— compression ratio	10 : 1
— max. torque	8.43 kgm a 6250 r.p.m.
— fiscal rating	12 HP
VALVE TIMING	O.H.C. with rods and rocker arms
FUEL FEEDING	no. 2 Dell'Orto carbs. PHM 40 ND (R.H.) PHM 40 NS (L.H.) type.
LUBRICATION	forced lubrication system with gear pump - wirenet and cartridge filters installed in the sump - standard lubricating pressure $3.8 \div 4.2$ kg/cm ² (controlled by a special valve installed on the sump) electric transmitter for insufficient pressure indication on the crankcase
ALTERNATOR/GENERATOR	installed on the front side of crankshaft (14V - 20A)
IGNITION	by ignition distributor with double breaker and automatic advance by centrifugal masses
— ignition data	first advance (fixed) $8^{\circ} \pm 1^{\circ}$ automatic advance $26^{\circ} \pm 2^{\circ}$ total advance (fixed + automatic) $34^{\circ} \pm 1^{\circ}$
— breaker points gap	$0.37 \div 0.43$ mm
— ignition spark plugs	BOSCH W5 DC
— spark plugs electrodes gap	0.6 mm
— ignition coils	no. 2 installed on the frame above the engine
STARTING	electric by start motor (12V - 0.7KW) equipped with electromagnetic control coupling crown gear fixed to the engine flywheel START push button placed right side on the handlebar
TRANSMISSIONS	
CLUTCH	dry type with two driven discs positionned on the engine flywheel controlled by lever on the left side of handlebar
PRIMARY TRANSMISSION	by gears, ratio 1.235 : 1 (Z = 17/21)
GEARBOX	five speed constant-mesh gearbox, front coupling. Built-in flexible coupling; control by pedal placed on the L.H. side of vehicle
— gearbox ratios:	
1st	1 : 2 (Z = 14/28)
2nd	1 : 1.388 (Z = 18/25)
3rd	1 : 1.047 (Z = 21/22)
4th	1 : 0.869 (Z = 23/20)
5th	1 : 0.750 (Z = 28/21)

SECONDARY TRANSMISSION by shaft with universal joint and gears

— ratio	1 : 4.714 (Z = 7/33)
— final drive ratio (engine-to-wheel):	
1st speed	1 : 11.647
2nd speed	1 : 8.088
3rd speed	1 : 6.100
4th speed	1 : 5.063
5th speed	1 : 4.367

FRAME

decomposable double cradle with tubular structure

SUSPENSIONS

— front	telescopic fork "MOTO GUZZI patent" with hydraulic shock-absorbers
— rear	swinging fork with adjustable springs concentric to the hydraulic shock-absorbers

WHEELS

— front	in light alloy with rims
— rear	16 MT 2.50 H2
	18 MT 3.00 H2

TYRES

— front	120/80 V 16"
— rear	130/80 V 18"
	Type: Tubeless or Tube-Type

BRAKES

— front	floating disc with fixed caliper and twin braking cylinder - manually controlled by handlever placed R.H. on the handlebar - hydraulic transmission independent from the rear brake: Ø disc 270 mm Ø braking cylinder 38 mm Ø pump 12.7 mm
— rear	floating disc with fixed caliper and twin braking cylinder - pedal control placed on the R.H. centre of the vehicle: Ø disc 270 mm Ø braking cylinder 38 mm Ø pump 15.875 mm the rear brake is connected by hydraulic transmission to the L.H. front brake having in its components the same dimensions as the R.H. front brake, hand controlled

DIMENSIONS AND WEIGHTS

— pitch (laden)	1.514 m
— max. length	2.160 m
— max. width	0.680 m
— max. height (windscreen)	1.220 m
— min. height from ground	0.120 m
— dry weight	215 Kg.

PERFORMANCES

— max. speed	230 Km/h with driver only
— fuel consumption	5.4 l./100 Km

REFUELINGS

— fuel tank	24 l. Super petrol (97 NO-RM/min)
(4 l. reserve)	
— engine sump	3 l. of «Agip SINT 2000 SAE 10 W/50» oil
— gearbox	0.750 l. of «AGIP Rotra MP SAE 80 W/90» oil
— transmission	0.250 l. of which: 0.230 l. of «Agip Rotra MP SAE 80 W/90»
(bevel gears lubrication)	and 0.20 l. of «Agip Rocol ASO/R» type oil
— telescopic fork (each leg)	0.150 l. of «Agip F.1 ATF Dexron» fluid
— front and rear brakes	«Agip F.1 Brake Fluid - SAE J 1703» fluid

5.1 DASHBOARD (fig. 306)

1 Key switch for connection as follows:

«OFF» in line with «C» mark: stopped vehicle. Key may be removed (no connection).

«A» in line with «C» mark (key turned in clockwise direction): vehicle ready to start. All devices are connected. Key cannot be removed.

«B» in line with «C» mark (key turned in clockwise direction): stopped vehicle. With «A» switch of fig. 307 in «PARK» position parking light is on. Key may be removed.

2 Voltmeter.

3 Rev. counter

4 Speedometer.

5 Trip recorder zeroing knob.

6 Warn. light (green light) for L.H. blinker.

7 Warn. light (green light) R.H. blinker.

8 Warn. light (bleu light) high beam on.

9 Warn. light (green light) parking lights on.


10 Warn. light («Neutral» green light) neutral pos. of gearbox. It is on only when gearbox is in this position.

11 Warn light (red light) generator current delivery. To be off when engine has reached a certain r.p.m. range.

12 Warn. light (red light) oil pressure. To be off when pressure is sufficient to insure engine lubrication. If the warn. light does not estinguish, pressure is not the prescribed one; in this case it is necessary to stop engine at once and investigate for the reason.

13 Warn. light (red light) starting the insufficient fluid level in the front L.H. and rear brake master cylinder. When this indicator is lit, fluid level has to be restored, at the same time checking that there is not leakage from the hydraulic system.

14 Emergency flashers switch (placed on the L.H. support of headlight).



306

5.4 LIGHTS SWITCH - HORN PUSH-BUTTON AND DIRECTION INDICATORS (fig. 307)

Placed L.H. on the handlebar.

«A» switch

«PARK» position parking lights.

«ON» position bilux lamp on.

«OFF» position lights off.


«B» switch

➔ position R.H. turn indicator.

➔ position L.H. turn indicator.

«C» push-button

horn control.



307

5.6 START PUSH-BUTTON LIGHTS CONTROL SWITCH AND ENGINE STOP SWITCH (fig. 308)

Installed on the R.H. side of handlebar.

With «A» mark on the key in line with the «C» mark (see fig. 306) vehicle is ready to start. To start engine act as follows:

- make sure that «B» switch is on central position;
- strongly pull the clutch lever («D» in fig. 307);
- if engine is cold, bring the «starter» lever on starting position;
- press on «A» start push-button.

To stop engine act on the ignition switch placed on dashboard.


To stop in an emergency case, «B» switch has to be turned upwards or downwards.

Once engine is stopped, turn key in the switch (fig. 306) in anticlockwise direction until the «OFF» mark is not in line with «C» mark, then extract the key.

«E» switch

With «A» switch (fig. 307) in «ON» position:

- «LO» position low beam.
- «HI» position high beam.
- «Flash» position flashing light.



308


5.18 FUSE HOLDER (fig. 309)

Placed in the central zone of motorcycle; to have access to it, remove the saddle.

In this seat you will find five fuses of 15 A.

Before replacing one fuse or more, the fault determining the blowing up must be detected (see «Electric system legend»).

- 1 Emergency flashers.
- 2 Direction indicators - Parking lights - Instrument cluster lights - Parking lights indicator.
- 3 High and low beams - Front brake «stop» light hydraulic control - Voltmeter - Brake fluid level, engine oil pressure, generator and neutral warn. lights.
- 4 Horn solenoid.
- 5 Starting solenoid and rear brake «stop» light hydraulic switch.




309

5.23 SADDLE LOCKING DEVICE (fig. 310)

Saddle is locked by a «A» special lockset placed L.H. in the rear side of motorcycle.

To unlock it, turn key a quarter of a turn in anticlockwise direction and strongly push the lockset. Saddle will be automatically lifted, so being removable.


To lock it, it is necessary to insert it into its seat on the frame and press on it.



310

6.1 CLUTCH LEVER ADJUSTMENT (fig. 311)

To adjust play between lever and handlebar connection, if higher or lower than $3 \div 4$ mm., act as follows: have the rubber diaphragm pulled back and actuate «A» setscrew up to the prescribed figures. Adjustment may be arranged also on «B» wire-stretcher, after having loosened «C» counternuts placed R.H. on the gearbox.




311

6.2 R.H. FRONT BRAKE LEVER ADJUSTMENT (fig. 312)

A certain play is foreseen between master cylinder float and control lever end.

It is possible to adjust this play, changing the «B» washers quantity placed on the STOP «A» switch positioned under the master cylinder transparent body.



312

6.4 REAR DAMPERS ADJUSTMENT (figg. 313 and 314)

Rear suspension spring load can be adjusted in three different positions, using special wrench «A» shown in fig. 313.


Moreover it is possible to adjust the damping effect of rear suspensions actuating «A» disc in fig. 314.

- In accordance with the specific needs and the bike load, there are four adjusting positions:
- 1 position very soft for a light load;
 - 2 position for bike use as solo or pilot plus pillion on good roads (for instance: highways);
 - 3 position for sport use as solo or pilot plus pillion with luggage;
 - 4 position very stiff, for use as pilot plus pillion and heavy luggage.


After some time of use and long journeys, to compensate the natural loss of damping effect, an higher adjustment of rear suspension could be necessary.

If you ascertain that damping effect of shock-absorbers is not correct or regular, have them checked at an authorized workshop of our dealers.

N.B. - For a good stability of motorcycle it is always advisable to ascertain that both shock-absorbers are adjusted on the same position, for what concerns the setting disc and the spring charge as well.



313



314


6.8 HEADLIGHT BEAM ADJUSTMENT (fig. 315)

Headlight has always to be directed at the correct height for a better security during riding and not to disturb the other vehicles met on the roads.

For the «horizontal» orientation, actuate «A» set-screw, while for «vertical» orientation use «C» set-screw up to reach the prescribed height.

At a distance of 3 m. the center of high beam has not to be higher than 0.833 m. with the motorcycle on the ground and pilot on the saddle.

Actuating «B» lever it is possible to quickly modify the vertical orientation in order to conform it to the loading conditions (with one or two passengers on the saddle).




315


7 MAINTENANCE AND LUBRICATION OPERATIONS

ITEMS ▼	COVERED MILEAGE ►	1500 km	3000 km	6000 km	9000 km	12.000 km	15.000 km	18.000 km	21.000 km	24.000 km	27.000 km	30.000 km
Engine oil		R	R	R	R	R	R	R	R	R	R	R
Oil filter cartridge		R					R					R
Wire gauze oil filter		C					C					C
Air filter				C	R		C	R			R	
Ignition timing		A	A	A	A	A	A	A	A	A	A	A
Spark plugs		A	A	A	R	A	A	R	A	A	R	A
Rocker clearance		A	A	A	A	A	A	A	A	A	A	A
Carburation		A	A	A	A	A	A	A	A	A	A	A
Nuts and bolts		A					A					A
Fuel tank, filters and pipes					C			C			C	
Gear box oil		A	A	A	R	A	A	R	A	A	R	A
Rear drive box oil		A	A	A	R	A	A	R	A	A	R	A
Wheel and steering bearings									A			
Fork legs oil									R			
Starter motor and generator									A			
Brake system fluid		A	A	A	A	A	R	A	A	A	A	R
Brake pads		A	A	A	A	A	A	A	A	A	A	A

A = Maintenance - Check - Adjustment - Eventual replacement / C = Cleaning / R = Replacement.
Time by time inspect battery electrolyte level and lubricate the control joints and hoses, every 500 Km. check the engine oil level.
In all cases renew oil at least once per year.



12.6 VALVES AND VALVE-GUIDES (fig. 317)



317

12.8 VALVE SPRINGS (fig. 318)

Check that springs are not out of shape or without any load; hereunder we state the involved data:


Outer spring

- **free**, it is 56 mm. long;
- **with closed valve**, it is 36 mm. long and it has to deliver $39 \pm 3\%$ Kg. load;
- **with open valve**, it is 26.5 mm. long, and it has to deliver $58 \pm 3\%$ Kg. of load;
- **in package**, it is $22.0 \div 22.5$ mm. long.

Inner spring

- **free**, it is 45 mm. long;
- **with closed valve**, it is 31 mm. long and it has to deliver $16.7 \pm 3\%$ Kg. of load;
- **with open valve**, it is 22 mm. long and it has to deliver $27.4 \pm 4\%$ Kg. of load;
- **in package**, it is $19.75 \div 20.25$ mm. long.

If the springs do not correspond to the above specifications, they have to be renewed.



318

12.12 CYLINDERS

Cylinders range (mm)

A SIZE	B SIZE	C SIZE
88.000 ÷ 88.006	88.006 ÷ 88.012	88.012 ÷ 88.018


12.13 PISTONS

Pistons range (mm)

A SIZE	B SIZE	C SIZE
87.968 ÷ 87.974	87.974 ÷ 87.980	87.980 ÷ 87.986

Pistons of an engine have to be balanced; only a difference of 1.5 gr. in weight is admissible.

When installing a piston, pay attention to the «SCA» (exhaust) wording to be directed towards the exhaust hole in the cylinder.



CRANKSHAFT BALANCE CHECKING

To statically balance the crankshaft it is necessary to apply to the crankpin a load of $1.650 \div 1.652$ Kg.

13 TIMING

13.1 TIMING DATA

The timing diagram with 1 mm. valve clearance is as follows:

Inlet

- opens 29° before T.D.C.
- closes 60° after B.D.C.

Exhaust

- opens 58° before B.D.C.
- closes 31° after T.D.C.

13.7 TAPPET CLEARANCE (fig. 320)

After the first 500 ÷ 1500 km. and afterwards every 3000 Km. or when timing adjustment becomes too noisy, check clearance between valves and rocker arms.

Adjustment must be made with **cold engine**, the piston being at T.D.C., compression stroke (closed valves).

After removal of head cover, act as follows:


- 1 loosen nut «A»;
- 2 screw in or out setscrew «B» until getting the following data:

- inlet valve 0.20 mm.
- exhaust valve 0.25 mm.

Seizes have to be taken using a special feeler gauge «C».

Take into account that when clearance is higher than the stated one, tappets are noisy, on the contrary valves do not close correctly causing the following inconveniences:

- pressure loss;
- engine overheating;
- valves burned out, ecc.



320

15 FUEL FEEDING

15.1 CARBURETORS (fig. 321)


No. 2 Dell'Orto «PHM 40 ND» (R.H.) and «PHM 40 NS» (L.H.) type.

Carburetors control:

- throttle handgrip R.H. on the handlebar;
- «starter» control lever (with **cold engine** installed on the L.H. side of crankcase).

Setting data

Atomizer	Ø 40 mm
Throttle valve	60.5
Spray nozzle	268 AB
Main jet	145
Idle jet	57
Starting jet	60
Pompe jet	35
Needle jet	K19 (3rd notch)
Float	10 gr
Idle mixture setscrew: 1 ½ turn.	




321

15.6 AIR CLEANER REPLACEMENT

Every 6000 Km. check the filtering unit condition and eventually clean it with compressed air; every 9000 Km. replacement is prescribed.

This air cleaner is installed on a special box together with the oil breather assembly, above the engine block.



FRONT FORK LEGS LUBRICATION (fig. 323)

For fluid renewal inside the front fork legs, act as follows:

- with the vehicle on the central stand, loosen «C» side screw fastening the steering head to the fork leg; disconnect the balance pipe and at the same time unscrew the «B» upper hex. head cap; then remove «A» draining plug;
- slightly press downwards the front side of motorcycle, you will obtain «B» cap coming out (this one being in one piece with the damper body).
- reinstall «A» plug and fill up with the prescribed quantity of fluid (150 cc. «Agip F.1 ATF Dexron»)
- through the space between the inner diameter of fork leg and damper body;
- reinstall «B» cap after having lifted the front side of the bike, and lock the side screw again. Repeat the same operations for the other side too.
- connect the balance pipe again and reset the dampers pressure in compliance with the prescribed figures.

OIL-PNEUMATIC SUSPENSIONS

The operation and charge pressure of front suspensions is as follows:



$$1.5 \div 2.5 \text{ Kg/cm}^2$$

For pressure checking, the use of a correct pressure-gauge is advisable, having a pipe as short as possible (without any pipe should be perfect), since the inner capacity of pipe could influence the pressure figure existing inside the shock-absorber.


In order to ascertain how much your pressure gauge reduces pressure inside the shock-absorber at every gauging, it is enough to arrange two successive measurements: difference between the two readings shows the pressure reduction operated at every gauging.

This measurement has to be taken with motorcycle on the central stand and cold shock-absorbers; for shock-absorbers charge use air without any trace of moisture.

N.B. - For more accuracy in checking, use the special pressure gauge no. 00950053.




323





324


FRONT FORK (fig. 325)

- Stroke 140 mm.
- Sleeve inner diameter:
40.010 ÷ 40.050 mm
- Fork legs outer diameter:
39.975 ÷ 39.950 mm




32!






Values in mm.

328



Values in mm.

329



330


23 WHEELS

23.20 FRONT WHEEL (fig. 331)


To remove this wheel from the vehicle, act as follows:

- place the vehicle on the central stand and have wheel lifted from the ground;
- unscrew screws «A» fastening calipers to the fork legs and remove calipers «B» with installed their pipes from the same fork legs;
- unscrew nut «C» fastening the axle on the R.H. side;
- loosen screws «E» fastening fork legs to the axle;
- extract axle «F» paying attention to installation of spacer «D»;
- extract front wheel from the fork legs;
- for installation, follow an inversed sequence, paying attention to the correct position of spacer;
- then repeatedly operate the brake levers in order to have caliper pistons at their normal position again.

NB - In accordance with the tyre type installed, it is necessary to deflate wheel before removal.



331




332

23.21 REAR WHEEL (fig. 333)


In order to remove the rear wheel from the swinging fork arm and transmission box, act as follows:

- place the motorcycle on the central stand;
- undo nut «A» with washer «B» on the spindle, box side;
- loosen screw fastening spindle «D» on the swinging fork arm;
- extract spindle «C» from the box, from the hub and the fork arm;
- remove plate «E» after having unscrewed «F» screws fastening caliper «G» to the same plate;
- position caliper «G» in such a way it is possible to fix it to the frame;
- bend and extract wheel from the swinging fork arm and from the transmission box.

In order to re-install wheel, follow an inversed sequence, taking into account to insert the complete plate with caliper on the L.H. arm stop of the swinging fork.



333



334

23.22 TYRES

Prescribed pressures are:

- front wheel: with one or two passengers: 2.2 kg/cm²;
- rear wheel: with one passenger: 2.4 kg/cm²;
with two passengers 2.7 kg/cm².

Above stated figures are for touristic riding. For use at high continued speed, or highways use, an increase in pressure of 0.2 Kg/cm² to the above figures is recommended.

23.23 BRAKE HYDRAULIC SYSTEMS

Pads wear checking

Every 5000 km. check pad thickness, to be:



- new pad 9 mm.;
- pad at wear limit 6 mm. about.

If thickness is lower than the wear limit, pads have to be renewed. After above renewal, brake system bleeding is not necessary, but it is sufficient to actuate lever «H» in fig. 308 repeatedly until the caliper pistons are returned to their normal position.


When renewing pads, check the conditions of hoses; if damaged, they have to be immediately replaced.

NB - In case of pads renewal it is advisable, during the first 100 km., to use brakes gently, with the purpose to allow a correct pads bedding.

R.H. front brake system and R.H. front brake control pump (fig. 335)



Rear and L.H. front braking system (fig. 337)




337

Air bubble bleeding from brake systems: rear and L.H. front braking circuit.

Instructions are as for 1000 SP and 1000 G5 models workshop manual, except the following points:

- 1 If the case, fill up the pump feeding tank;
- 2 Arrange bleeding acting on «F» caliper, after having removed it from the supporting flange and placed in such a position that «L» bleeding plug is directed upwards (fig. 338).



338

IGNITION

Advance figures

- Initial advance (fixed) $8^{\circ} \pm 1^{\circ}$
 - Automatic advance $26^{\circ} \pm 2^{\circ}$
 - Total advance (fixed + automatic) $34^{\circ} \pm 2^{\circ}$
- Breaker point gap $0.37 \div 0.43$ mm.

Spark plugs

Spark plug types to be used are:


Bosch W 5 DC.

Electrode gap: 0.6 mm.

For cleaning use petrol, metallic brush and a needle for inner cleaning.

When installing spark plugs again, **pay attention they are correctly fitted and easily screwed in their seats**; in case of bad connection they should be damaged in the head thread; by consequence we suggest to hand-screw them for a few turns, then to use the special wrench in the kit, avoiding to tighten.

Even if spark plugs appear in very good conditions, after 9000 Km. about they have to be renewed.



339

Electric system scheme legend

- 1 Headlight.
- 2 High and low beam (55/60 W bulb).
- 3 Parking light (4 W bulb).
- 4 15-way connector (Molex).
- 5 9-way connector (Molex).
- 6 9-way connector (Molex).
- 7 3-position ignition switch.
- 8 Voltmeter (3 W bulb).
- 9 Speedometer (3 W bulb).
- 10 Rev. counter (3 W bulb).
- 11 R.H. blinkers warn. light (1.2 W bulb).
- 12 Brake fluid level warn. light (1.2 W bulb).
- 13 Oil pressure warn. light (1.2 W bulb).
- 14 Generator warn. light (1.2 W bulb).
- 15 Neutral gear warn. light (1.2 W bulb).
- 16 Parking light warn. light (1.2 W bulb).
- 17 High beam warn. light (1.2 W bulb).
- 18 L.H. blinkers warn. light (1.2 W bulb).
- 19 Simultaneous flasher switching.
- 20 R.H. front direction indicator (21 W bulb).
- 21 L.H. front direction indicator (21 W bulb).
- 22 R.H. rear direction indicator (21 W bulb).
- 23 L.H. rear direction indicator (21 W bulb).
- 24 High and low beam control device - Light flashing - engine starting.
- 25 Horns device - Lights control switch and direction indicators.
- 26 Bi-tonal trumpets.
- 27 Front brake STOP switch.
- 28 Rear brake STOP switch.
- 29 Rectifier.
- 30 Alternator (14 V 20A21).
- 31 Regulator.
- 32 Battery.
- 33 Starting solenoid.
- 34 Start motor.
- 35 Fuse holder.
- 36 Rear STOP light.
- 37 Rear parking and number plate light.
- 38 Tail light.
- 39 Flashing device (12 V 42/92 W).
- 40 Brake fluid level signal.
- 41 Neutral pos. signal.
- 42 Oil pressure signal.
- 43 Coils.
- 44 Spark plugs.
- 45 Breaker.
- 46 Trumpet solenoid.
- 47 80Ω-2W resistance.

Fuse 1: Emergency blinkers light.



Fuse 2: Direction indicators, Parking lights, instrument cluster lights, parking light warn. light.

Fuse 3: High and low beam, front stop light switch, voltmeter, neutral pos. warn. light, generator, oil pressure, brake fluid.

Fuse 4: trumpet solenoid.

Fuse 5: Starting solenoid, rear stop light switch.

IGNITION SWITCH POSITIONS:
 1st pos.: No contact
 2nd pos.: All connections activated
 3rd pos.: 16/30 connection activated



- A = Orange
- AZ = Light blue
- BI = White
- B = Blue
- G = Yellow
- M = Brown
- N = Black
- RO = Pink
- R = Red
- V = Green
- VI = Violet
- BI-AZ = White/Light blue
- BI-N = White/Black
- B-N = Blue/Black
- N-GR = Black/Grey
- R-BI = Red/White
- R-B = Red/Blue
- R-G = Red/Yellow
- R-N = Red/Black
- V-GR = Green/Grey
- V-N = Green/Black